

## 4 CHANNEL FM TRANSMITTER

This FM transmitter is designed to transmit audio to any FM receiver! It works with MP3 players, CD players, and any other music source. It allows you to set FM channel at 88.1MHz, 88.3MHz, 88.5MHz, 88.7MHz. Just tune your FM radio to match the same frequency of this unit, and it turns your FM radio audio into a MP3 player right away.

① Plug FM transmitter adapter into your music player.



② Tune FM transmitter and your stereo to the same FM frequency 88.1, 88.3, 88.5 or 88.7.



③ Turn FM transmitter on and music transmits from player to stereo.

### FM-110

AC/DC 12VDC Adaptor 12VDC Auto Adaptor

**1. Modulation: FM Stereo Modulation**

**2. Frequency Range: Four Channels at 88.1MHz, 88.3MHz, 88.5MHz, 88.7MHz**

**3. Audio Input Connector : 1/8-inch (3.5mm) Stereo Plug**

□ **4. Power Requirement: 2 "AAA" Alkaline Batteries or 12VDC Auto Adaptor or AC/DC 12VDC Adaptor**

□ **5. Battery Life : 13 hours typical**

□ **5. Frequency Response: 50 Hz to 15 kHz**

□ **6. Operating Range: 10-30 feet**